


3RD ANGLE PROJECTION DO NOT SCALE

Wiring List		
J1	J2	Signal Name
25 way D-Type	50 way IDC Header	
1	26	422_OUT_3-
14	27	422_OUT_4+
2	28	422_OUT_4-
15	29	GND
3	30	GND
16	31	422_IN_1+
4	32	422_IN_1-
17	33	422_IN_2+
5	34	422_IN_2-
18	35	422_IN_3+
6	36	422_IN_3-
19	37	422_IN_4+
7	38	422_IN_4-
20	39	GND
8	40	GND
21	41	TTL_OUT5V_1
9	42	TTL_OUT5V_2
22	43	TTL_OUT5V_3
10	44	TTL_OUT5V_4
23	45	TTL_IN5V_1
11	46	TTL_IN5V_2
24	47	TTL_IN5V_3
12	48	TTL_IN5V_4
25	49	GND
13	50	GND

Unused Pins		
J2	1 - 25	





Pyramid Imaging Inc

945 East 11th Avenue
Tampa, FL 33605
https://pyramidimaimging.com
Sales@pyramidimaging.com
(813) 984-0125

Mechanical Overview FireBird I/O Adapter

All dimensions in millimetres (mm) and for reference only

© 2020 Active Silicon Limited

m DRAWN DATE
Keith Baker 27-Jan-20

Active Silicon

TITLE

etical.

MO-AP20-0066-0201

1 SHT No. A 2 of 2 3

Whilst every effort has been made to ensure that the information contained in this drawing and the associated CAD data in electronic form is accurate and correct, Active Silicon cannot be held liable for errors or omissions. Should any errors or omissions be discovered, Active Silicon will use all reasonable endeavours to correct and re-issue the drawings and CAD data as fast as practical.